




LED Flashlight Q3 LED 500 Lumen 9 Watt
Product Code: 96756



Operating Instructions for LED flashlight

Proper care and use of this product will provide years of dependable service.

General Operation



The LED Flashlight features a tail switch that allows convenient use without awkward two-handed twisting or turning. Simply depress the pushbutton switch located at the rear of the flashlight to turn the flashlight "on". Depress the switch again for "off". Depressing the switch TWICE to activate MOMENTARY BLINK, HIGH BRIGHT,

BRIGHT, LOW BRIGHT & SOS function of the switch.

The LED Light is "fixed" at the optimum focus point and is not adjustable.

WARNING: The LED flashlight utilizes a high wattage bulb that can get very hot. Never lay the flashlight face down against a flat surface. Never lay the flashlight in a way that minimizes the chance that it will accidentally be turned on.

Batteries

The LED flashlight uses one rechargeable 18650 battery. To recharge the battery, loosen the charger connection next to the head of the flashlight widdershins. Then plug the charger output to the charge connection and connect the charger input to electricity plug. The light on charger is red while recharging and changes to green when recharging is complete. If recharging is needed when the battery is not empty the light on charger will be green after plugged in correctly. Depress the pushbutton and the light will change to red signifying recharging has started. When recharging is complete the light changes to green. After charging is complete pull out the charger plugs and fasten the charger connection.

WARNING: These lithium batteries represent a fire, explosion, and burn hazard.

DO NOT OPEN the battery, dispose in fire, recharger, heat above 200 degrees Fahrenheit, expose contents to water, put in backwards, or mix with used or other battery types-may explode or leak and cause personal injury.