



## LED Flashlight 3 Watt CREE P4 LED 160 Lumen Product Code: 37564

### Operating Instructions for LED flashlight

Proper care and use of this product will provide years of dependable service.

### General Operation

This LED Flashlight features a tail switch that allows you convenient use without awkward two-handed twisting or turning. Simply depress the pushbutton switch located at the rear of the flashlight to turn the flashlight "on". Depress the switch again for "off".



The LED Light is "fixed" at the optimum focus point and is not adjustable.

**WARNING:** The LED flashlight utilizes a high wattage bulb that can get very hot. Never lay the flashlight down against a flat surface. Transport or store the flashlight in a way that minimizes the chance that it will accidentally be turned on.

### Batteries

The LED flashlight uses 1 PCS AA battery. To change the batteries simply unscrew the flashlight tail and remove the batteries. Insert the new cells with the positive contacts pointing toward the flashlight head. Replace the flashlight assembly and flashlight head. Tighten the head of the flashlight until it seals fully.

**WARNING:** These lithium batteries represent a fire, explosion, and burn hazard.

**DO NOT OPEN** the battery, dispose in fire, recharger, heat above 200 degrees Fahrenheit, expose contents to water, put in backwards, or mix with used or other battery types-may explode or leak and cause personal injury.